# **SIEMENS**

HiPath 4000 Hicom 300 E/300 H

Operating Instructions optiPoint 500 entry



# **About these Operating Instructions**

These Operating Instructions describe the use of the optiPoint 500 entry telephone in conjunction with the HiPath 4000 Communication Server, Version 1.0 and Hicom 300 E/300 H, all Versions.

They describe all functions you can use from your telephone. You may find that some functions you wish to use are not available on your telephone. This may be due to one of the following reasons:

- The function has not been configured for your telephone address any questions to Customer Support.
- Your communications platform does not support this function contact your Siemens sales representative to upgrade your system.

# **Important Notes**

	Never operate the telephone in an environment where there is a risk of explosion.
ORIGINAL Responsibility	Only use Siemens accessories. The use of other manufacturers' accessories may be dangerous and will render the warranty and approval null and void.
	Never open the telephone set. If any problems arise, get in touch with System Support.
	The telephone must not come into contact with abrasive liquids or liquids which are liable to discolour it, such as tea, coffee, fruit juices or soft drinks.  Care of the telephone → page 53.

### **CE** label



The CE symbol certifies compliance of this equipment with the EU directives.

## **Environmental label**



This device has been manufactured in accordance with our certified environmental management system (ISO 14001). This process ensures that energy consumption and the use of primary raw materials are kept to a minimum, thus reducing waste production.

Basic operating instructions  optiPoint 500 entry control panel.  How to use these Operating Instructions  How to access a function  using codes  using UK codes, Standard codes, Euro codes, special codes and system codes  using a function key		
igcup Basic and enhanced-convenience functions		
Taking calls and setting up calls10Taking a call10Open listening within the room during a call10Taking a call on a line key (keysystem working)11Holding a call on a line key (not for UK)11Continuing a call on a line key (not for UK)11Using call waiting12Activating/de-activating call waiting12Answering a waiting call12Using the mailbox (not for UK)13Retrieval from mailbox13Answering a callback request13Activating/deactivating do not disturb14		
Setting up calls15Dialling with the handset off-hook15Dialling with the line key (keysystem working)15Dialling with the handset on-hook15Suppressing the number display at the called party16Entering commands with tone dialling (DTMF suffix dialling)16		
Calling several persons simultaneously17Making a second call (consultation)17Making a conference call18Setting up an add-on conference18Extending a call19Using the switchover key (HiPath 4000)20		

System-wide parking (HiPath 4000)	21
Parking a call	21
Parking via the keypad	21
Parking via "system parking"	
Taking a parked call	
Via the keypad	
Parking via "system parking"	
Using stored numbers to make calls	23
Saved number redial	
Last number redial	
Dialling with individual speed dialling numbers	
Dialling with system speed dialling numbers	24
If you don't get through	25
Using the callback facility	
Storing a callback request	25
Answering a callback request	
Cancelling a stored callback request	
Camp-on or override	26
Telephone settings	27
Adjusting the volume of the ringing tone	27
Adjusting the pitch of the ringing tone	
Setting the volume of the alerting tone	
Setting the receiving volume during a call in progress	
Preventing misuse of the telephone	29
Storing numbers	31
Storing a number for redialling	31
Storing a caller's number or a number	
which has been dialled	
Storing any number	


Forwarding calls 33
Using forwarding (Hicom 300 E/300 H)
Using fixed call forwarding
Forwarding calls automatically
Using variable call forwarding
Using forwarding (HiPath 4000)
Call forwarding via code numbers
Delayed call-forwarding (HiPath 4000)
Forwarding calls for a different terminal
Storing a destination for another
telephone/activating call forwarding
Storing a destination for fax, PC
or "busy"/activating call forwarding
Deactivating call forwarding for fax, PC or "busy"
Changing call forwarding for another terminal
Using a different telephone
in the same way as your own 43
Logging on to a different telephone
Deactivating identification at the other telephone
Delegating with the telephone
Relocating with the telephone 45
Disconnecting the telephone from its present station line
Reconnecting the telephone at the new station line
Using HiPath 4000 as a
intercommunication system 46
System-wide voice-calling
Voice calling in a group
Announcement to all members of a line group
Team functions
Making calls in a team 50
Taking a call for a colleague
Parking a call and picking it up within the team
Taking a call in a hunt group
Removing station from hunt group/adding station to hunt group 51


# $\begin{picture}(100,0) \put(0,0){\line(0,0){100}} \put(0,0){\line(0,0){10$

Labelling and documentation      Attaching the number label	. <b>52</b>
Documentation	. 52
Advice for users	. 53
Care of the telephone	53
Index	. 54
Important functions at a glance	. 55
List of codes	. 57

# **Basic operating instructions**

## optiPoint 500 entry control panel





## **How to use these Operating** Instructions

The operating procedures are presented in a logical sequence in the "coloured" column. The symbols used have the following meanings:



Lift the handset.



Replace the handset.

Enter the number or code.



Enter the PIN.



• or 
Press volume controls on the telephone.



You hear a tone.

A long tone (positive confirmation tone) confirms that you have successfully activated a function or procedure. A short tone (negative confirmation tone) indicates that the function or procedure was rejected.



Press the key.

Press the key which is lit.

Press the key which is flashing.

#### How to access a function

#### ... using codes



Activating call forwarding



Activating call forwarding



Entering a callback request



Cancelling a callback request

When you activate or switch on a function, you always begin by pressing the "star" key; when you deactivate, switch off or cancel a function, you always begin by pressing the "square" key.

As the examples show, codes can consist of either one or two digits.

# ... using UK codes, Standard codes, Euro codes, special codes and system codes

System Support will inform you which codes apply to your Hicom 300 H system.

The **Appendix** to these Operating Instructions contains an overview of the possible codes.

If your optiPoint 500 entry does not have a "store" key, storage of a call forwarding destination can be initiated by **lifting the handset** and dialling the special code. **Replace the handset** once you have entered the call forwarding destination (→ page 33).

Note that all these types of codes are included in the descriptions in the central part of these Operating Instructions.

#### ... using a function key

You can activate directly those functions for which a key has been programmed, for example:

Consultation

Press the key. The function is executed (if it is available in the particular situation).

# Taking calls and setting up calls

# Taking a call

The telephone rings.



Lift the handset.

#### Terminating a call:



Replace the handset.

# Open listening within the room during a call

You can allow other persons in the room to listen in on the call. Always inform the other party that you are switching on the loudspeaker.

You conduct the call with the handset.

#### To activate:




Press the key. The lamp lights up.

#### To deactivate:



Press the key. The lamp goes out.



# Taking a call on a line key (keysystem working)

**Precondition:** There is a line key with its own number on your telephone.

The telephone rings. The line key lamp flashes rapidly.



Lift the handset.



Hold

Press the key. The lamp lights up.

# Holding a call on a line key (not for UK)

Precondition: Your telephone has a "Hold" key.

Press the key. The line key lamp flashes slowly.



Your HiPath 4000 system can also be configured in such a way that the call is held when the line key is pressed. Try this for yourself or enquire with System Support.

# Continuing a call on a line key (not for UK)



Press the key. The lamp lights up.

## **Using call waiting**

If you are expecting an important call, it is a good idea to activate the call waiting function. If you are in the middle of a call, you will then be made aware there is a call. waiting. You can accept or ignore the waiting call.

### Activating/de-activating call waiting

#### **Activation**

Waiting call

Press key. Lamp comes on.

#### **De-activation**

Waiting call

Press key. Lamp goes out.

## Answering a waiting call

**Precondition: You are telephoning.** The call-waiting function is activated.



You hear the alerting tone. The lamp flashes. The caller hears the ringing tone as if you were "free." Press key. You are now connected to the waiting caller. The first party then waits.

#### Waiting call over, first call is continued:



Press key.



Replace the handset and lift again.

# Using the mailbox (not for UK)

**Precondition:** The "mailbox" and "output" keys have been configured on your telephone.

Callers who dialled your number during your absence can leave a callback request in your mailbox. You will also find mail server voice/fax messages in your mailbox (if this facility is available).



#### **Retrieval from mailbox**




Lift the handset.



The lamp lights up if the mailbox contains new entries which have still to be retrieved.

Press the key.

The first callback request is announced.



Next callback request:

Press the key again.



Answering a callback request



Lift the handset when the other party answers.

## **Activating/deactivating do not disturb**


**Precondition:** System Support has enabled the do not disturb facility for all HiPath 4000- and Hicom 300 users in your system.

If you do not wish to receive incoming calls, you can activate the do not disturb facility. Internal callers then hear ringing tone, while external callers are forwarded to the attendant

#### To activate:




Lift the handset.



UK code or Standard code



Euro code.



Enter the code which has been programmed for you.




Replace the handset.

#### To deactivate:



Lift the handset.



UK code or Standard code



Euro code.



Enter the code which has been programmed for you.

Replace the handset.



The attendant can override the do not disturb facility.

# **Setting up calls**



# Dialling with the handset off-hook



Lift the handset.



Internal: Enter the number.
External: Enter the external code and the number.

#### The called party is busy or does not answer:



Replace the handset.

# Dialling with the line key (keysystem working)

**Precondition:** There is a line key with its own number on your telephone.



Lift the handset.



Press the line key. The lamp lights up. The line has been seized automatically.



Internal: Enter the number.

External: Enter the external code and the number.

# Dialling with the handset on-hook



Internal: Enter the number.

External: Enter the external code and the number.

#### The called party answers via the speaker:



Lift the handset.



#### The called party is busy or does not answer:

Press the key. The lamp goes out.


# Suppressing the number display at the called party

Suppression of the number indication only applies to the next call and is not stored together with the redial function.


#### To activate:



Lift the handset.



UK code or Standard code/Euro code.



Enter the code which has been programmed for you.

Enter the other party's number. If the call is answered, your number does not appear on the called party's display (if the telephone has a display).


#### To deactivate:



Lift the handset.



UK code or Standard code/Euro code.



Enter the code which has been programmed for you.

Replace the handset.

# Entering commands with tone dialling (DTMF suffix dialling)



This feature is not applicable for UK and other countries using tone dialling (default).

After dialling a number, you can set tone dialling in order to activate equipment - such as an answering machine or an automatic information or switching system - by means of command inputs in DTMF mode (DTMF = dual-tone multifrequency dialling).



Switch over to tone signaling.

# Calling several persons simultaneously



# Making a second call (consultation)

You can set up a second call during a call in progress. The first party waits.

Consultation

Press the key. The lamp lights up.

Make your call to the second party.

Disconnect/Clear

Terminate the second call – return to the first party:

Press the key.

## Making a conference call

With a conference circuit, you can converse with up to seven other persons simultaneously. These can be internal or external users.

### Setting up an add-on conference



Lift the handset.



Call the first user.



After speaking to the first user: press the key. The lamp lights up.



Call the second user. The first party waits.



After speaking to the second user: press the key. The lamp lights up.



Consultation

Conference

Enter the UK code or Standard code for conference.

If your telephone does **not** have a "conference" key: Enter the code for conference.

A tone indicates that all three users have been interconnected to form a conference circuit.

All three parties can now converse with one another.

## **Extending a call**

**Precondition:** The consultation key has been installed on your telephone.

If the person you are conversing with wishes to be forwarded to another user, you can pass on the connection to this third person.

The connection can be passed on with or without prior announcement.

#### **Extending the call with prior announcement:**

Consultation

Press the key. The lamp lights up.



Call the other party and inform him that the waiting user wishes to be put through to him.



Replace the handset.

The two users are connected to each other.

#### **Extending the call without prior announcement:**

Consultation

Press the key. The lamp lights up.



Enter the other party's number.



Replace the handset.



If a connection is not set up between the other two parties within 40 seconds, you are recalled. You are then connected to the first party again.

## **Using the switchover key (HiPath 4000)**

You can use the switchover key, which must be installed by the system administrator beforehand, for the following functions:

- Consultation (back to the waiting party or back to the waiting conference)
- Toggling
- Accepting a waiting call (the call-waiting function must be activated see → page 12)
- Accepting a group call


#### **Call waiting**

You hear a camp-on busy tone.

Press the flashing key. You accept the camp-on call. The lamp comes on.

#### **Toggling**

You are connected to two subscribers: one is waiting. The switchover key is illuminated.



Switchover

Press the key to select the other subscriber. The first subscriber is waiting.

#### Consultation

You call a second subscriber. The second subscriber does not respond.



Press the key to return to the waiting subscriber or the waiting conference.

#### **Group calls**

You are connected to a subscriber. There is a pending group call.



Press the flashing key. You accept the group call; the 1<sup>st</sup> subscriber is put on hold. The lamp comes on.

# **System-wide parking** (HiPath 4000)

On the HiPath 4000, you can park up to 10 internal and/ or external calls and take them at another telephone. There are two ways of parking a call:

- Manual parking
- Parking with the "system parking key"

Parking is **not** possible if:

- The park position you want is occupied
- The subscriber is the operator
- The call is a consultation call
- The call is a conference call


## Parking a call

You can automatically park a call to your telephone in a free parking position and take it at your telephone or another telephone.


### Parking via the keypad




Press key. The lamp comes on.



Enter the system code for system parking (if you have any problems ask the system administrator).







### Parking via "system parking"



Press key (must be installed).



Enter and note a parking position number (0 to 9).

The call is parked.




Replace the handset.

## Taking a parked call

#### Via the keypad



Lift the handset or use the speakerphone function.



Enter the system code for system parking (if you have any problems ask the system administrator).




Enter the parking position number (0 to 9) you have noted and continue the call.

## Parking via "system parking"



Lift the handset.




Press key (must be installed).



Enter the parking position number (0 to 9) you have noted and continue the call.

### Parking is not possible

If the selected parking position is occupied, or there is some other reason why parking is not possible, you will hear the busy tone.



Press the illuminated key and continue the call.



or


Replace the handset. The held call is recalled.

# Using stored numbers to make calls

### Saved number redial

**Precondition:** The "redial" key is configured on your telephone.

If your telephone is configured for this type of redialling, you can store a number and then dial it at a later point in time ( $\rightarrow$  page 31). You can redial the number at the push of a button.



or **43** 

Lift the handset.


Press the key.

UK code.

#### Last number redial

**Precondition:** The "last number redial" key is configured on your telephone.

If this type of call forwarding is configured on your telephone, **each** (last) number dialled is saved automatically for possible redialling.



Lift the handset.

Last no. redial Press the key.

# Dialling with individual speed dialling numbers


**Precondition:** You have stored individual speed dialling numbers (→ page 32).



Lift the handset.



UK code or Standard code/Euro code



Enter the code which has been programmed for you



Enter the special code (not for UK).



and

Enter the speed dialling number.

# Dialling with system speed dialling numbers



You will be supplied with a copy of the system (central) speed dialling directory by System Support (for example) or you will find it in the inhouse telephone directory or your PC.

After selecting a speed dialling number which is the stored destination for another telecommunications system, you can immediately suffix-dial the station number you require.

# If you don't get through...

## Using the callback facility

If an internal station which you have called is busy or there is no reply, you can place a request for callback. This also applies to external calls via ISDN switching centres. This saves you having to dial the number repeatedly. You are then called back

- as soon as the other party terminates his call
  - as soon as the other party makes a further call
- as soon as the other party checks his mailbox and responds to your callback request (→ page 13).

You can only place one request for callback at a time.

### Storing a callback request

**Precondition:** The station which you have called is busy or there is no reply.

Callback

or \*\* 0 or \*\* 9

Press the key. The lamp lights up.

UK code or Standard code

## **Answering a callback request**

The telephone rings.



Lift the handset. Ringing tone can be heard.



If you do not answer a callback request within four rings, the request is cancelled.

### **Cancelling a stored callback request**


**Precondition:** You have stored a callback request.



Lift the handset.



UK code or Standard code



Enter the code which has been programmed for you.

Replace the handset.

## Camp-on or override


In order to camp-on or override, you must have the correct class of service.

Depending on the configuration of your telephone, System Support will have programmed **either** "camp-on" **or** "override".

**Precondition:** The **internal** station user whom you have called is busy. You need to contact this person urgently.



UK code or Standard code/Euro code



Enter the code which has been programmed for you.

#### Camp-on (call waiting):

The user hears an alerting tone in the course of the call. The "Call pickup" key flashes on his telephone. If his telephone has a display, your name and number are indicated.


#### Override (call entering/intrusion):

The user hears an alerting tone. You can speak immediately.



Camp-on is not possible if the called party is protected by camp-on rejection or station override security.

# **Telephone settings**



# Adjusting the volume of the ringing tone

- Press one of the keys when the telephone is in the idle state.
  - Press the key.
- or 
  To increase/decrease the volume: keep pressing the keys until the required volume level has been reached.
- cogether Store.

# Adjusting the pitch of the ringing tone

- or 

  Press one of the keys when the telephone is in the idle state.
  - Press the key.
- or 
  Changing the pitch: keep pressing the keys until the required pitch has been reached.
- cogether Store.

# Setting the volume of the alerting tone

You hear alerting tone if a call has not been picked up in your team.

• or — Press one of the keys when the telephone is in the idle

Press the key.

To increase/decrease the volume: keep pressing the keys until the required volume level has been reached.

(+) (-) together Store.

# Setting the receiving volume during a call in progress

**Precondition:** You are conducting a call.


• or 
To increase/decrease the volume: keep pressing the keys until the required volume level has been reached.

(+) (-) together Store.

## Preventing misuse of the telephone

You can prevent unauthorised persons from using your telephone during your absence.


**Precondition:** You have been assigned a personal identification number (PIN) by System Support.



#### Preventing unauthorised dialling:




Lift the handset.



UK code or Standard code



Euro code



Enter the code which has been programmed for you.





Enter the PIN (code number).



Replace the handset.




When the telephone is disabled in this way, a special dial tone is audible when the handset is lifted. Internally (within HiPath 4000), dialling is possible in the usual way.

### **Enabling the telephone again:**




Lift the handset.



UK code or Standard code



Euro code



Enter the code which has been programmed for you.

and



Enter the PIN (code number).



Replace the handset.


# **Storing numbers**

## Storing a number for redialling

**Precondition:** Your telephone is programmed for "Saved number redial" **not** "Last number redial".

# Storing a caller's number or a number which has been dialled

You have set up a call and are still engaged in this call. Or you have been called by – and are still conversing with – a user whose number has also been communicated to you.



Press the key.



UK code.




Replace the handset.

#### Storing any number



Press the key. The lamp lights up.






UK code.



Enter the number.




Press the key. The lamp goes out.



You can dial the stored telephone number at the push of a button ( $\rightarrow$  page 23).


# Storing individual speed dialling numbers

You can store a number on each of digit keys 0 to 9 and then dial these numbers at the push of a button (→ page 24). An existing number is overwritten.



Press the key. The lamp lights up.

UK code or Standard code/Euro code



Enter the code which has been programmed for you.




If your telephone does **not** have a "store" key:

Lift the handset and enter the special code (not for UK).



Enter a specific speed dialling number (0 to 9).





Press the key. The lamp goes out.

If you have already lifted the handset and entered the special code:

Replace the handset.

# Forwarding calls

## Using forwarding (Hicom 300 E/300 H)

## **Using fixed call forwarding**

Fixed call forwarding can be activated in a matter of seconds. It is advisable to use this type of call forwarding in order to reroute calls to the mailbox or to a permanent deputy, for example.

#### Storing/changing a destination



Lift the handset.




Press the key. The lamp lights up.





Press the key again.

Without pressing the keys first:




UK code or Standard code.

If the "store" and "call forwarding" keys are **not** configured on your telephone:




Lift the handset and enter the special code (not for UK).





Press the key. The lamp goes out.



Replace the handset.

Fixed call forwarding is activated immediately.



If your line is also accessible at other telephones, the relevant line keys are all affected by the call forwarding function.

#### Cancelling a destination

Store

Press the key. The lamp lights up.

Call forwarding

Press the key.

Call forwarding

Press the key again.

Without pressing the keys first: UK code or Standard code.

or (1) (6) Euro code.

If the "store" and "call forwarding" keys are **not** configured on your telephone:

or and to a Lift the handset and enter the UK code.

or (15) Special code (not for UK).

Disconnect/Clear Press the key.

Store Press the key. The lamp goes out.

If you have already lifted the handset and entered the special code:

Replace the handset.

#### **Deactivating call forwarding**

Call forwarding Press the key. The lamp goes out.

If your telephone does **not** have a "call forwarding" key:

or and 1111 Lift the handset and enter the UK code

or (1) (1) or Standard code.

Replace the handset.

#### **Activating call forwarding**

Call forwarding Press the key. The lamp lights up.

If your telephone does **not** have a "call forwarding" key:

or and and Lift the handset and enter the UK code

or X 4 or Standard code.

Replace the handset.

### Forwarding calls automatically

A call is diverted to the fixed call forwarding destination even if you have not activated fixed call forwarding (and provided that your system is configured for this facility).

If "forwarding ring no answer" (transfer of ringing) has been programmed, calls are rerouted automatically if, for example, they are not answered after several rings or they arrive when you are already engaged in a call.

### Using variable call forwarding


Each time you activate variable call forwarding, you specify the destination number to which calls are to be diverted. You will find variable call forwarding particularly useful if you have to divert calls to frequently changing destinations.

#### Storing a destination/activating call forwarding



If configured: press the key.

Press the key. The lamp lights up.



Press the kev.

If the "store" and "call forwarding" keys are **not** configured on your telephone:



Store

Lift the handset and enter the UK code



or Standard code



Enter the number of the destination.



Press the key. The lamp goes out.


If you have already lifted the handset and entered the special code:

Replace the handset.

Call forwarding is thus activated.



If you enter a number belonging to a networked HiPath 4000 system, you must conclude input with ...



#### **Deactivating call forwarding**

Press the key. The lamp goes out.

If your telephone does **not** have a "call forwarding" key:

or  $\nearrow$  and  $\bigcirc$   $\bigcirc$  or  $\bigcirc$ 

Lift the handset and enter the UK code

or Standard code

Replace the handset.

# **Using forwarding (HiPath 4000)**

You can program two forwarding modes:

- "Fixed forwarding" and
- "Variable forwarding"

With fixed forwarding, you program a forwarding destination that remains valid until you modify or clear it.

You can activate/de-activate this forwarding mode.

With variable forwarding, you can select one of six different forwarding types.

When you program a forwarding destination, you activate forwarding. If forwarding is de-activated, the forwarding destination is automatically cleared.

### **Call forwarding via code numbers**

The following call-forwarding modes can be set up via codes:

Call-forwarding mode	Code (example)
Programming and activating fixed call-forwarding	*51
Activating fixed call-forwarding	*41
Clearing (and de-activating) fixed call-forwarding	#51
De-activating fixed call-forwarding	#41
Programming and activating unconditional, variable call-forwarding	*42
Programming and activating variable call- forwarding for internal calls	*44
Programming and activating variable call- forwarding for external calls	*43

Call-forwarding mode	Code (example)
Programming and activating variable call- forwarding on busy	*45
Programming and activating timed, variable call-forwarding	*46
Programming and activating variable call-forwarding (on busy/timed)	*47
De-activating variable and fixed call-forwarding	#41
De-activating variable call-forwarding for internal calls	#44
De-activating variable call-forwarding for external calls	#43
Activating system call-forwarding	*90
De-activating system call-forwarding	#90

#### Programming and activating call-forwarding



Lift the handset.



Enter a code number, say \*51, (ask system administrator). You will hear the dialing tone.



Enter the number of the destination.



Enter the terminating character. You should hear a confirmation tone, call forwarding has then been activated.



Replace the handset.

## **Activating fixed call-forwarding**



Lift the handset.



Enter a code number, say \*41, (ask the system administrator).




Replace the handset.

## **Deactivate call-forwarding**



Lift the handset.



Enter a code number, say #41, (ask the system administrator).



## Call-forwarding via call-forwarding key

Call-forwarding keys for all call-forwarding modes (see Table → page 36) can also be installed by the system administrator. When programming the call-forwarding destination, enter the destination call number too.

#### Programming and activating call-forwarding



Lift the handset



Press the call-forwarding key. The lamp comes on.



Enter the destination call number.



Enter the terminating character. You should hear a confirmation tone – call-forwarding has then been activated




Replace the handset.

#### **Activating fixed call-forwarding**



Lift the handset.



Press the fixed call-forwarding key. The lamp comes on.



Replace the handset.

## Call forwarding

Press key. Lamp goes out.

De-activating call-forwarding

## **Delayed call-forwarding (HiPath 4000)**

Installed for the whole system by the system administrator.

**Requirements:** Waiting call must be installed (→ page 12).

If you have activated "call-forwarding on busy / timed " or "timed call-forwarding" on your telephone (see Table → page 36), you will automatically obtain a camp-on busy tone if there is a waiting call. This gives you the opportunity to take the call before it is forwarded (say you are waiting for an urgent call).

A calling party hears the ringing tone and is only forwarded to another telephone when the time that has been set elapses.

## Forwarding calls for a different terminal

You can store, activate, check and deactivate call forwarding for another telephone, fax machine or PC from your own telephone. To do so, you need to know the PIN for this terminal or you must have the "Call forwarding for remote terminal" class of service.

**Precondition:** The "store" key is configured on your telephone.

## Storing a destination for another telephone/activating call forwarding



Lift the handset.



UK code or Standard code/Euro code.



Enter the code which has been programmed for you.



Enter the number of the other telephone and confirm your input with the square key.



Enter the PIN of the other telephone and confirm your input with the square key.



Press the square key only (if your own station has the "Call forwarding for remote terminal" class of service).




Enter the number of the destination and confirm your input with the square key.



Press the square key only (the telephone on which you are storing call forwarding thus becomes the call forwarding destination).

Wait for the acknowledgment tone.




Press the key. The lamp goes out. Call forwarding is thus activated.



## Storing a destination for fax. PC or "busy"/activating call forwarding



Lift the handset.



Press the key. The lamp lights up.

Enter the code for the type of call forwarding required. The codes are defined by System Support. You can enter your call forwarding codes in the following table:

"Call forwarding for fax":	*43
"Call forwarding for PC":	*42
"Call forwarding for busy":	*49



Enter the number of the other terminal and confirm your input with the square key.



Enter the PIN of the other terminal and confirm your input with the square key.



Press the square key only (if your own station has the "Call forwarding for remote terminal" class of service).



Enter the number of the destination and confirm your input with the square key.



Press the square key only



(the terminal at which you are storing call forwarding thus becomes the call forwarding destination).



Press the key. The lamp goes out. Call forwarding is thus activated.




## **Deactivating call forwarding for another telephone**



Lift the handset.



UK code or Standard code/Euro code.



Enter the code which has been programmed for you.



Enter the number of the other telephone and confirm your input with the square key.



Enter the PIN of the other telephone and confirm your input with the square key.



Press the square key only (if your own station has the "Call forwarding for remote terminal" class of service).



Enter the number of the destination and confirm your input with the square key.



Press the square key only (the telephone on which you are storing call forwarding thus becomes the call forwarding destination).

Wait for the acknowledgment tone.




Press the key. The lamp goes out.



## Deactivating call forwarding for fax, PC or "busy"



Lift the handset.



Press the key. The lamp lights up.

Enter the code for deactivating the particular type of call forwarding. The codes are defined by System Support. You can enter your call forwarding deactivation codes in the following table:

"Deactivate call forwarding for fax":	#43
"Deactivate call forwarding for PC":	#42
"Deactivate call forwarding for busy":	#49



Enter the number of the other terminal and confirm your input with the square key.




Enter the PIN of the other terminal and confirm your input with the square key.



Press the square key only (if your own station has the "Call forwarding for remote terminal" class of service)

Wait for the acknowledgment tone.



Press the key. The lamp goes out.



Replace the handset.

## Changing call forwarding for another terminal

The procedure is exactly the same as for Store/Activate:

for another telephone  $\rightarrow$  page 39, for fax, PC or busy  $\rightarrow$  page 40.

# Using a different telephone in the same way as your own

You can log on to another telephone belonging to the Hicom system by means of a personal identification number (PIN) (as of software status HiPath 4000, Version 1.0 und Hicom 300 E/300 H, and also telephones of networked HiPath 4000 systems, e.g. at other branches of your company). At the other telephone you can then:

- make calls and assign the charges to cost centres
- use your individual speed dialling numbers and also a number which has been stored at your own telephone for the purpose of redialling.

In addition, you can have your calls diverted to a telephone in the office or department where you will be for a temporary period ("call forwarding - follow me").

## Logging on to a different telephone


**Precondition:** You have been assigned a PIN by System Support. You require an internal PIN for calls within your own HiPath 4000 system, while for calls involving other HiPath 4000 systems in the integrated network you require a "network-wide" PIN.



Lift the handset.



UK code or Standard code (for PIN 1).



Enter the code for additional PIN.

Entering the PIN for your own HiPath 4000 system area:



Enter internal PIN.



Entering the PIN for another HiPath 4000 system area within the integrated network:



Enter the 2-digit node code for your own HiPath 4000 system (enquire with System Support).



Enter your own number and press the square key.

Enter the network-wide PIN and press the square key.

#### Dialling after (successful) identification:

You hear dial tone.

or



Enter a number immediately.

## Call forwarding – follow me after successful identification



UK code or Standard code/Euro code.

Enter the code!

die bei Ihnen eingerichtete Kennzahl eingeben.

Replace the handset.

# Deactivating identification at the other telephone



Lift the handset.



UK code or Standard code/Euro code



Enter the code which has been programmed for you.



Replace the handset.



Depending on the configuration of the system, identification is deactivated automatically if the far-end telephone is not used for several minutes.

## Relocating with the telephone

Enquire with System Support whether this is possible with your telephone system.

After **consulting with System Support**, you can deregister your telephone from its present station line and then re-register it at the new station line. Note that the settings on your telephone (programmed keys) are not affected by the move.

## Disconnecting the telephone from its present station line




Lift the handset.



Enter the code for de-registration. If you are not sure of the code, enquire with System Support.



Enter the PIN.




Remove the telephone plug from the socket.

## Reconnecting the telephone at the new station line

Insert the the telephone plug in the socket.



Lift the handset.



Enter the code for registration. If you are not sure of the code, enquire with System Support.



Enter the PIN.



# Using HiPath 4000 as a intercommunication system

You can voice call an internal HiPath 4000 user via the loudspeaker in his or her telephone to set up a connection. You can also initiate voice calling from consultation. The following functions are available:

- System-wide voice calling
- Voice calling in a group
- Announcement to all members of a line group

You can abort voice calling or the announcement by replacing the handset or pressing the line key or by picking up the call on hold during consultation.



For all functions ensure that the **voice calling protection** for the telephones in question has been **de-activated**. With optiPoint 500 entry, voice-call protection is de-activated via a key that has been installed by the system administration.

If a user is voice called and his or her voice-call protection has been activated, voice calling is ignored and a normal call is put through instead.


## **System-wide voice-calling**

From your telephone, you can voice call any internal user whose telephone has a speakerphone function or a loudspeaker.

A destination subscriber is voice called via his or her internal call number




Lift the handset.



Enter the system code number for "voice calling" and



the internal call number of the user.



Press the "voice calling" key (must be installed beforehand)

#### and



enter the internal call number of the user.

An immediate connection is made to the destination loudspeaker if

- there is no busy condition
- · the handset has not been lifted
- and voice-calling protection has not be activated

The calling party will hear a confirmation tone indicating that the connection has been set up and that he or she can start talking.

The called party can accept the call by lifting the handset.

If the called party presses the loudspeaker key or the line key (if installed), the connection is aborted.



The number of possible voice calls is the same as the number of possible normal calls.

## Voice calling in a group


A normal connection within a group or team (for team call = speed-calling number for team members 0 to 9 or 00 to 99) can also be set up via Voice calling. To do this, voice calling is initiated from a group telephone.



The "voice calling in the group" function is lineindependent – anyone can voice call anyone else.



Lift the handset.



Enter the system code-number for "voice calling in the group" and



the speed calling code for the group member in question.





Press the key for "voice calling in the group" (must be installed)

#### and



the speed calling code for the group member in question.

A connection to the destination loudspeaker is set up immediately, if

- there is no busy condition
- the handset is cradled
- and voice-calling protection has not been activated.

The called party accepts the voice call by lifting the handset.

If the called party presses the loudspeaker key or the line key (if installed), the connection is aborted.


# Announcement to all members of a line group

Using this function, you can make a simultaneous announcement to all members (10 to 40) of a line group.

After you have set up the group call, you will receive a confirmation tone which tells you that you can start your announcement.



Lift the handset.



Enter the system code-number for "announcements" and



the internal call number of a group member.



Press the "announcement" key (must be installed)



enter the internal call number of a group member.

The loudspeakers of all group telephones are automatically activated and you will hear a confirmation tone. You can now start your announcement..

End your announcement by replacing the handset or pressing a line key.

If a group member lifts a handset, he or she is connected to you and the announcement is terminated.

If a group member presses the loudspeaker key or the relevant line key for the announcement, he or she is disconnected from the announcement. If the last remaining member of the group presses the loudspeaker key or the line key, the announcement is terminated.

## Making calls in a team

## Taking a call for a colleague

If a member of a team does not answer a call within 15 seconds (depending on the system), the other members of the team hear an alerting tone.

#### Telephone in the idle state:

Lift the handset and press the flashing key. You have picked up the call.

Press the flashing key only.

You are in the open listening mode.

#### **During a call:**

Press the flashing key.

The first party is placed on hold while you are connected to the second party.


#### Terminate the second call - return to the first call:

Press the key.

## Parking a call and picking it up within the team

You can park a call within the call pickup group on one telephone and then continue it at a different telephone.

#### Parking the call:




Replace the handset.

#### Resuming the call:

Press the flashing key. Continue the call.









Call park

Call park

## Taking a call in a hunt group

Precondition: A hunt group has been configured in the team.

You - and all the members of the team - can be accessed by way of a hunt group number.

Your telephone rings.



Lift the handset.

## Removing station from hunt group/ adding station to hunt group

You can disconnect yourself from the hunt group at any time, e.g. when you leave the office. You can rejoin the hunt group as soon as you return to the office.




You can still be contacted via your own number when you have been disconnected from the hunt group.

#### Disconnecting:




Lift the handset.



UK code or Standard code



Euro code




Enter the code which has been programmed for you.

## Rejoining:




Lift the handset.



UK code or Standard code



Euro code



Enter the code which has been programmed for you.



## **Labelling and documentation**

## Attaching the number label

A sheet of number labels is supplied with each telephone.

Fill in the number label (fire service, police, own number), peel it off and attach it to the recess on the telephone (after lifting the handset).

## **Documentation**

You can find these operating instructions in the Internet in PDF format under

#### http://www.hipath.com

and on CD-ROM (ask System Support) in HTML and PDF format.

The CD-Rom (7 languages) or a printout of these operating instructions can be ordered from the details of the article number from Siemens' Sales Organisation of via the following Internet address.

#### http://www.click4business-supplies.de

CD-ROM article number: P31003-H1012-C130-\*-6Z19 Article number of these operating instructions: A31003-H8400-B305-2-7619

In order to look at and print the operating instructions in PDF format, you need a computer on which the free Acrobat Reader software package is installed by Adobe.

To look at the operating instructions in HTML format you need a computer with a www browser, e.g. Microsoft Internet Explorer.

## **Advice for users**



## Care of the telephone

- Use either a damp cloth or an antistatic cloth to clean the telephone set. Never use a dry cloth!
- If the telephone set needs to be cleaned thoroughly, use a neutral, diluted, surface-active cleaning agent. Take care that all traces of the cleaning agent are removed with a damp cloth (using water only!).
- Never apply a cleaning agent which contains alcohol or which is liable to harm plastic surfaces; never use an abrasive cleaning powder.

## How to deal with malfunctions

#### There is no response after a key has been pressed:

Check whether the key has become stuck.

## No ringing tone when an incoming call is received:

Check whether you have activated the do not disturb facility (→ page 14). If you have, cancel it in order to receive calls again.

#### All other faults:

First get in touch with System Support. If the fault cannot be eliminated, Customer Service must be called in.

## Who to contact if a problem occurs

In the case of faults which last longer than 5 minutes, for example, please get in touch with System Support.

#### Index L Lamp ......7 Α M Add-on conference ......18 Automatic call forwarding ......35 callback request ......13 retrieving ......13 C Call pickup (team) ......50 Call waiting ...... 12 N Call, parking a ......21 Number label 52 Number suppression ......16 answering ......25 storing .......25 Callback request ......13 0 cancelling ......14 Open listening ......10 CF label 2 P Conference 18 Consultation 17 Parking a call ......50 D R Deactivating ......44 Do not disturb facility ......14 Relocation 45 Ringing tone pitch ......27 Ringing tone volume ......27 E Euro code ...... 57 S Extending a call ......19 Special codes ......9 F Standard code ......57 Fixed call forwarding ......33 Switchover key ......20 Forwarding calls ......33 т Н Taking a call ......10 Hold ......11 on a line key ......11 Hunt group ......51 V Variable call forwarding ......35 Identification at another telephone deactivating ......44 Individual speed dialling numbers dialling ......24 storing ......32

## Important functions at a glance

## Making a call: Either: + Or: + when the other party answers ..... Making a call with a line key: **)** + **!!!**. + Line Redial (saved number): Store: Either: The connection has been set up: Redial Or: Any number: Store + Redial + Store Repeat: + Redial Redial (last number dialed): + Last no. redial Taking a call with a line key: + Line **Enabling others in the room to listen in:** Speaker Information during a call in progress (consultation): + second party Consultation To terminate: Disconnect/Clear

## Extending a call:

With prior announcement: Consultation + + announce call, + -.

Without prior announcement: Consultation + + + +

#### Setting up a conference call:

First call Consultation + Conference

In the case of a telephone with no "conference" key:

First call Consultation + + + + G for UK or \*3.

Expanding conference (to include up to 8 users):

Add-on conference Consultation + + + + G for UK or \*3 etc.

#### Storing/activating variable call forwarding:

Store + Call forwarding + (destination) + Store

In the case of a telephone with no "store" and "call forwarding" keys:


→ + ★ 1 1 for UK or \*44 + (destination) + → ...

### Activating/deactivating fixed call forwarding:

Deactivating: Call forwarding or (#111) for UK or #44.

Activating: Call forwarding or \*44.

## **Cancelling destination for fixed call forwarding:**



In the case of a telephone with no "store" and "call forwarding" keys:

+ e.g. (1) for UK + -...

## Storing individual speed dialling numbers:

Store + **3** 6 4 for UK or **#8** + **1** (0..9) + **4** (destination) + Store

In the case of a telephone with no "store" key:

+ + (0..9) + (destination) + ...

## Dialling with individual speed dialling numbers:

→ + ★6 for UK or \*8 or ★ ② (a) (not for UK) + → (0..9).

## **List of codes**

For information on the use of codes please refer to  $\rightarrow$  page 9.

Function	UK code	Standard code	Euro code ①	Special code ②
Camp-on/override	* 6 0	* 1 9	* 19	
Do not disturb on/off	*51/#51	*40/#40	*93/#93	
Fixed call forwarding on/off	*11/#11	*44/#44		
Fixed call forwarding – storing destination	* 2 1	* 4 9	* 9 6	* 5 6
Fixed call forwarding – cancelling destination	#21	#49	#96	#56
Variable call forwarding – storing destination	* 1 1	* 4 4		* 4 4
Variable call forwarding off	#11	#44		#44
Call forwarding for another terminal on/off	*14/#14	*411/#411	*411/#411	
Pick up the call	* *	* 7		
Display suppression own number on/off	*24/#24	*50/#50	*50/#50	
Identification on/off (then enter PIN)	*8/#8	*51/#54	*51/#54	
Call forwarding - follow me after identification	* 1 4	* 4 1 1		
Conference	* 9	* 3	* 3	
Storing individual speed dialling numbers	* 6 4	# 8 and 0-9	# 8 and 0-9	#28
Dialling individual speed dialling numbers	* 6 3 and 0-9	* 8 and 0-9	* 8 and 0-9	* 2 8
DTMF suffix-dialling (after suc-	* #	* #	* #	
cessfully dialling an external number) ③				
Storing callback	* 0	* 9		
Cancelling callback	# 0	# 9		
Disconnecting oneself from hunt group	#52	* 1 3	* 9 5	
Rejoining hunt group	* 5 2	#13	#95	
Locking/unlocking telephone to prevent misuse	*49/#49	* 18 / # 18	*92/#92	
Redial: storing number	* 7	* 6		
Redial: dialling stored number	#7	# 6		

<sup>① Recommendation
② for optiset E without store key
③ This feature is not applicable for UK and other countries using tone dialling (default)</sup> 



1P A31003-H8400-B305-2-7619

The information provided in this document contains merely general descriptions or characteristics of performance which in case of actual use do not always apply as described or which may change as a result of further development of the products. An obligation to provide the respective characteristics shall only exist if expressly agreed in the terms of contract.

Reference No.: A31003-H8400-B305-2-7619 • Printed in the Federal Republic of Germany © Siemens Enterprise Communications GmbH & Co. KG 2002
Siemens Enterprise Communications GmbH & Co. KG is a Trademark Licensee of Siemens AG